

HEAT PUMP CLEANER



Heat Pump Cleaner is a unique non foaming heavy-duty cleaner specifically designed for the cleaning of heat pumps and heat exchangers. By ensuring that your evaporator or condenser is clean ensures optimal energy efficiency and better performance.

GENERAL INSTRUCTIONS

1. Before using the product always ensure that the system is shut down and power has been disconnected.
2. At a distance of at least 5cm (50mm) spray the unit to be cleaned evenly starting from top to bottom. Ensure that the heating/cooling spiral is completely covered with the cleaner.
3. Allow Heat Pump Cleaner to soak on the treated area for approximately 5-10 minutes.
4. Wipe the treated area with a clean microfibre cloth to remove all debris.
5. Then wipe with a clean cloth to remove the dirt, and rinse lightly with fresh water.

Please note: For heavily soiled Heat Pumps a second application may be necessary.

PRODUCT ADVANTAGES

- ✓ Ready to Use product – no need for dilution.
- ✓ Can be used on both Evaporators and Condensers.
- ✓ Noncorrosive – will not damage the heat pump fins.
- ✓ Fast cleaning time or no more than 5 – 10 minutes.

PROFESSIONAL TIPS

By regularly cleaning your Heat Pump you can increase the COP. This is achieved by ensuring maximum air flow through the fins. This will provide an optimal balance between the recovered energy and issued energy.

For further information go to our website www.lo-chlorchemicals.com