

POOL TIGER INSTALLATION



- Pool Tiger does not require an electrical connection.
- It settles quickly (15 minutes on average depending on the site).
- As soon as the appliance is installed, it is ready for operation.
- It must be installed last, before the water goes back into the pool. It works in all positions (horizontal, inclined, vertical...).
- As soon as the water pump is running and the water is flowing, the Pool Tiger is working.
- 2 models: 21m3 / h and 57m3 / h and Installation on tube 50 or 63 mm.



The steps to follow:

- Stop the filtration.
- Make sure that the pipes are drained before starting the installation.
- Place the Pool Tiger, it is the last device before the water returns to the pool,
- Check that it is positioned in the correct direction, the blue arrow on Pool Tiger indicates the direction of water flow.
- Thoroughly clean the hoses with a detergent.
- Use a PVC glue, to assemble the pipes to Pool Tiger.
- When the glue is dry, turn on the water pump to check that there are no leaks.







